



COMPACT
User manual

www.mobi-click.com

More security in all situations!

Product description: What is Mobi-Click "Compact"?

Important information

At first: change the PIN-code!

Switch on Mobi-Click Compact

Mobile phone, emergency and alarm system at the same time!

How do I save the 3 phone numbers?

My first phone call with Mobi-Click Compact

Switch on the alarm standby with another mobile phone

What should I do in case of an alarm?

How will I be informed per SMS in case of an alarm?



How do I choose the right alarm instruction?

Can I change the sensitivity of the sensors?

Whether everything is set correctly? Test!

What is the meaning of the SMS messages?

Eavesdrop in? Yes, but pay attention...!

PIN-Code - How to protect against outside access?

Can I write personal alarm messages?

How can I test if the text is correct?

Individual SMS-instructions

Security zone and localization of persons or objects

How can I connect extern devices?

Declaration of Conformity

Technical data

Product description: What is Mobi-Click "Compact"?

The easiest
mobile phone...

Mobi-Click Compact works nearly like a usual mobile phone, just much more easier! You can receive any calls and dial three pre-programmed phone numbers directly.

for seniors:

Mobi-Click Compact is suitable as an emergency system for elder and handicapped persons. With these three numbers you can call for example your doctor, your daughter or the emergency call service directly.

for children (and anxious parents):

With the three coloured buttons, Mobi-Click is also the perfect mobile phone for children because parents can always contact their children.

and alarm system:

As an alarm system Mobi-Click protects you in different situations:

Car theft and burglary:

With Mobi-Click Compact you can protect your vehicle against theft or your flat, your house or your office against burglary.

Baby phone:

As a Baby phone Mobi-Click alarms you immediately if your child is crying or climbing out of bed.

In case of an alarm you are going to receive up to three SMS or phone calls on your three pre-programmed numbers. You have the possibility to contact undetected Mobi-Click from any phone and so listen in the room quietly.


You can protect your Mobi-Click with a PIN-code, so that only you or any allowed person can communicate with Mobi-Click quietly.

Important information

1. First steps before using the Mobi-Click Compact

Mobi-Click **Compact** possesses an integrated circuit for the protection of the battery from over and under charging as well as from short-circuit. This protective circuit is activated with a small slide switch (see design). In order to avoid damage during transport, this slide switch is set to the OFF position at the factory. Before first use the protective circuit must be activated by moving the slide switch from the OFF to the ON position.

(View of the **Compact** from the rear)



To set the Compact in operation

- Open the rear cover
- Open the SIM-card caddy
- Using a pointed tool, move the slide switch to the ON position
- Insert SIM-card
- Close the SIM-card caddy
- Close the rear cover
- Connect the battery charger
- A peep signals indicates that the **Compact** has successfully started

3.

Important information

1. Leave the **Compact** connected to the battery charger for a minimum of 40 Minutes to ensure that the battery is fully charged.
2. Before switching on the **Compact** (with the ON/OFF key) the battery charger must be disconnected. Once **Compact** is switched on, the battery charger can be connected or disconnected as required, or be permanently connected. This way, a temporally unlimited working time of **Compact** can be guaranteed (e.g. monitoring during a vacation).
3. **Compact** allows the user a variety of programming options and adjustments of the device functions to suit individual requirements of the user. If during the programming something does not really work, you can reprogram the device, reset the **Compact** by moving the reset switch (located under the rear cover) to the OFF position for a minimum of 5 seconds and then ON again. This does not erase previous settings, but sets the **Compact** ready to receive new instructions. Restart the **Compact** after resetting.

PIN

At first: change the PIN-code!

As Mobi-Click Compact has only 3 buttons and a ON/OFF power button some settings have to be done on a second "normal" mobile phone at the first use.

These settings have to be done just once!

Changing of the PIN-code

For the use of Mobi-Click Compact you also need a SIM-card which is like the SIM-cards you need for other mobile phones. It does not matter which SIM-card you choose, a prepaid-card or a SIM-card with subscription with an operator. Put the SIM-card, which you are going to use for Mobi-Click Compact later, in a "normal" mobile phone first.

Every SIM-card has a PIN-code. Since Mobi-Click utilises its own PIN system to guard against unauthorised access by SMS. Therefore the original PIN-code of the SIM card must be changed (see your mobile phone handbook for changing PIN instructions). For changing PIN you can use any mobile telephone.

Place the SIM card intended for use in the Mobi-Click into any mobile phone. Using the mobile phone's menu, navigate to the changing PIN code option (see your mobile phone handbook for changing PIN instruction) and change the PIN-code as follows:


new PIN-Code: **1513**.

In case of any problems read the instructions of your operator or the instructions of your mobile phone manufacturer.

After changing the PIN-code of your SIM-card, remove the SIM-card from your mobile phone and place it into Mobi-Click Compact. Open the small cover at the bottom of Mobi-Click Compact and place the SIM-card into the SIM caddy. Carefully replace the cover.


ATTENTION!

Mobi-Click Compact works only when you delete all messages you have in the "inbox" of your SIM-card.



Start

Switch on Mobi-Click Compact



You need

- 1 Mobi-Click Compact
- 1 SIM-card
- 1 mobile phone for changing the PIN-code of the SIM-card and to program the three phone numbers

Connect Mobi-Click

- Ensure the Mobi-Click is turned OFF and connect the battery charger to ensure that the battery is fully charged. You will hear a short peep tone when the charging cycle begins.
- Orange LED is blinking: the battery is not charged
- Switch on your device as described on the left page. You should NOT turn on the Mobi-Click with the charger connected. An integrated protection circuit is built into the Mobi-Click to ensure that the battery delivers optimal supply to the Mobi-Click.

What to do if...

- ...there is no dual tone and the green LED does not light?
- Is the device switched on?
 - Does the battery have enough power?
 - Is the PIN-code changed, and is the SIM-card inserted correctly?
 - Attention! **General Reset** (s. pages 4 and 37)

Security advise

Mobi-Click Compact was produced by keeping to the strict manufacturing and quality controls. Thus your device works correctly and to prevent that the guarantee expires there has to be considered the following security councils:

- Take care of your Mobi-Click Compact.
- Mobi-Click is full of electronics and sensitive sensors. Therefore do not drop Mobi-Click, do not expose Mobi-Click any hard hit as the electronic printed circuit board could get any defect because of this.
- Moisture, heat or cold could influence the perfect work of the device strongly and lead to damages.
- Do not try to open the Mobi-Click device. Thus you damage the housing and you loose the guarantee service.

Multifunctions

Mobile phone, emergency and alarm system at the same time!

Activate as mobile phone	Activate as emergency system	Activate as alarm system	Activate test mode
 GREY Press when switching on (power ON/OFF).	 RED +  ON/OFF Keep the two buttons pressed when switching on until you hear a signal tone!	 BLUE +  ON/OFF Press the two buttons when switching on until you hear a signal tone!	 GREEN +  ON/OFF Press the two buttons when switching on until you hear a signal tone!
Set up connection	If it is ringing	During phone call	Switch on alarm standby
(RED)  Dial the 1st number	(GREEN)  Reject call	(BLUE)  Switch to mute	 AUTO Car monitoring
(GREEN)  Dial the 2nd number	(RED)  Answer the call loudly	(BLUE)  Hear loudly (free speaker)	 HOME Protection against burglary
(BLUE)  Dial the 3rd number	(GREEN)  Answer the call normally	(RED)  Hang up	 BABY Baby phone
Emergency mode: The call will be answered automatically after 1 ring.	Emergency mode: Hear the call automatically loudly (free speaker).		Press the button until the countdown starts (peep...peep...). You now have 15 seconds to leave of the room. To switch off: press the button again.
			In the test mode Switch on: press the same buttons as described on the left. With the test mode you can test the different sensors. In case of an alarm you hear a siren. Switch off: Press the chosen number again.
			In an emergency case: In case of an alarm the three SMS or phone numbers will be informed. See page 20 and 21.

Start

How do I save the 3 phone numbers?

As easy as SMS...

With Mobi-Click Compact you can dial three different numbers, without the tiring typing of the phone numbers: just press one of the three coloured buttons and you are connected directly to the number you have chosen!

Before you can profit from this short dialling, you have to save those three numbers first. (You can change them easily at any time). Therefore you need a normal mobile phone.

At first you have to choose a number for every coloured button.

Start Mobi-Click Compact in the alarm mode!

Press and hold the blue button at the same time as pressing the ON/F OFF button (see page 11)

For every single number you have to create an SMS on a normal mobile phone and send it to Mobi-Click Compact. You can also send and save all three number simultaneously using the **set key** command (see page 13).

After the numbers have been saved, switch off the Mobi-Click and restart Mobi-Click in mobile phone mode.

ATTENTION!

Even if you have one or more of these three numbers set as SMS in alarm mode – in telephone mode always this number will be called independently of the alarm set-up.

Entering on a normal mobile phone

2

Write a SMS instruction:

e.g.: Set TEL1 +41791234567 red button: 1. receiver

3

Send SMS instruction to Mobi-Click Compact

31.03.2004 10:11
COMPACT 42

Tel1 = call
004191123456

8
e.g.: Next number:
continue with 1
e.g.: Set TEL2 004179111...
e.g.: Set TEL3 +4152765...

Activate Mobi-Click Compact in the alarm mode (see page 11)

1



Activate as alarm system (page 11)

4

The number is saved:
button 1 (red)


- TEL1... red button
- TEL2... green button
- TEL3... blue button

5

Confirmation of
the SMS instruction

6

triple tone




- Please consider the space bars between single words / numbers: Set(space bar)TEL2(space bar)+41...
- Always include intl. prefixes for intl. phone numbers (e.g. 0041 or +41 for Switzerland).
- Use capital or small letters or both.
- Every new SMS-order deletes the old one!
- You can store all three numbers at one time by sending the instruction **set key** followed by the three numbers you wish to send to the Mobi-Click Compact. This acts the same as the instruction for only one number (e.g. set TEL/SMS1). (Note! The spaces between the three numbers must be inserted!)

Start

My first phone call with Mobi-Click Compact

Dial the number



If it's ringing...

- (RED) Reject call
- (GREEN) Answer the call **loudly**
- (BLUE) Answer the call **normally**

Answer a call automatically – more security for people who live alone or handicapped persons:



Answer a call automatically:
Elderly and handicapped person are often living alone. Especially this group of people is often exposed to dangerous situations: a fall or an unexpected collapse could have bad consequences.

When the call is **answered automatically** you can contact your beloved person directly whenever you want: Mobi-Click Compact answers automatically and put the hear- and speaking settings to "loud" (free speaker), thus the person do not have to pick up the telephone.

Switch on alarm standby

Switch on the alarm standby with another mobile phone

As easy as a SMS...

Mobi-Click Compact can be set per SMS instructions with every normal mobile phone. Therefore you should be able to write and send SMS messages on your mobile phone, then you are also able to serve Mobi-Click. All settings of Mobi-Click are made by a simple principle:

- ▶ Write a SMS on your mobile phone.
- ▶ Send this SMS to the Mobi-Click Compact


SMS instructions consist of 2 words:

1. word: what do I want to do?

Set = switch on
Reset = switch off
Test = test

2. word: determine situation or sensors

Auto = vehicle monitoring
Home = room monitoring
Baby = baby phone



In case of alarm


What should I do in case of an alarm?

Keep cool!

A Mobi-Click alarm message has always to be taken serious! Keep cool in any case and consider your next steps exactly:

- ▶ Which persons were be alarmed?
Control: send instruction "**Test SMS**" to Mobi-Click.
- ▶ If you were alarmed per SMS:
Send the instruction "**Hear**" to Mobi-Click.
Mobi-Click calls you back quietly immediately.
- ▶ If you were called:
Do not hang up! Now you can listen in the monitored room/place quietly. After about 2 minutes the connection will be disconnected by Mobi-Click, but before it will be hanged up, you will hear peep tone twice (so you know you were connected to Mobi-Click).
- ▶ If the alarm standby is not switched off then there will be sent a new alarm message after 5 minutes if necessary.

Activate Compact as alarm system



On your own mobile phone

(example of an alarm SMS)

- 1 You receive a short message (SMS) on your mobile phone:

31.03.2004 10:11
COMPACT.42
Message: An alarm was released!
AREA : off mid
MOVE : ALARM mid
VOICE : ALARM mid

- 2

Write SMS instruction and send to Mobi-Click Compact:

- 3
- 4 If you pick up you can listen quietly in the room
- 5

Hear

Reset ...

Home
Baby
Auto
All
...



Always your mobile phone...

Please ensure that you have saved ALL the numbers that you wish Mobi-Click to alarm in event of an alarm (see page 12-13)



Do you want to be called if there is an alarm?

By switching on the alarm standby add the word "**Call**" to the instruction.

Example:
Set baby (normal)
Confirmation and alarm message per SMS.

Set baby call
Confirmation of Set Baby will be received by a call on your mobile phone. In the event of an alarm there will be a call or SMS to your mobile phone depending on your saved settings.

Alarm messages

How will I be informed per SMS in case of an alarm?

Triple security!

In case of an alarm Mobi-Click Compact can call 3 alarm numbers altogether and therefore send up to three different persons a SMS or make a phone call to them. (see also information by e-mail, page 37).

Examples:

You want to monitor a holiday house. In case of an alarm Mobi-Click should


- ▶ send 1 **SMS** to your mobile phone
- ▶ send 1 **SMS** to the mobile phone of your wife
- ▶ make 1 **call** to a fix net number

The setting looks like:


- ▶ Set **SMS1 +41791234567**
(Your personal mobile phone number)
- ▶ Set **SMS2 0041791112233**
(Mobile phone number of your wife)
- ▶ Set **TEL3 +41527654321**
(Number of your fix net telephone)

On your own mobile phone

If the alarm message should be sent per **SMS**:



If the alarm message should be made per **call**:



SMS only in alarm mode!

You can save 3 numbers altogether with Mobi-Click Compact.

If you use Mobi-Click Compact as a mobile phone you can dial these three numbers directly with the three coloured buttons.

The same numbers are used to make an alarm call or to send a SMS (message) like described here, if alarm standby is activated.

For professionals:

Alarm number...

(Send all instructions from your mobile phone to Mobi-Click Compact):

control:

Test SMS

You receive a short message with a list of all alarm numbers.

change:

e.g. Set **SMS2 004179555...**
Old number 2 will be overwritten.

switch off:

e.g. Reset **SMS2** (leave empty)
Number 2 will be deactivated.

restart:

e.g. Set **SMS2** (leave empty)
The old number 2 will be reactivated.

switch off all:

Reset **SMS** (leave empty)
All numbers (SMS/TEL) switched off except number 1.

Set Auto Mobi-Click for the car



Vehicle theft

With Mobi-Click Compact you protect your vehicle (car, machine, motorbike, etc.) reliably and without any problems against thieves and burglars. The **Vibration-sensor** reacts on smallest vibrations (shut the car door, drag s.o. off, etc.) and causes an alarm message immediately per SMS or phone call to up to 3 pre-programmed numbers.

In case of a vehicle theft there will appear constantly the appropriate **location message** (GSM zone code) on your own mobile phone display where the vehicle is located at the moment. Mobile phone operators and the police are able to locate your vehicle because of this information.

Right placement

To install Mobi-Click is not as expensive as to install an alarm device in a car repair shop: just hide it in your vehicle (e.g. in the glove compartment, in the trunk or also under the seat).

Activate the alarm system



Press the two buttons when switching on until you hear a signal tone!

Activate alarm standby (auto)



Press red button for about 3 seconds. Countdown starts (peep... peep...). You have 15 seconds to leave your car. To turn off: press red button within 15 seconds.

Start

- ▶ Activate the alarm system as described above. Mobi-Click Compact is now ready. To activate car monitoring function press the red button. Now the countdown starts automatically (peep...peep...). Quickly hide Mobi-Click Compact in your car and leave. After 15 seconds Mobi-Click is ready.
- ▶ The alarm function can also be activated from another mobile phone: just send the following SMS-command to Mobi-Click Compact "**set auto**".
- ▶ Switch off Mobi-Click Compact:
 - When you enter your vehicle you can switch off your Mobi-Click Compact by pressing the red button. Remember: you only have 15 seconds time, before the alarm starts! (When the alarm is turned off, you hear a triple tone.)
 - Or:
send the following SMS-instruction from your mobile phone to Mobi-Click Compact: "**reset auto**". The monitoring will be switched off.

Set Home

Mobi-Click at home



Burglary

With Mobi-Click Compact you can monitor your flat, your house or office reliably: The **Motion-sensor** registers persons which move within a distance of 5 meters. If a stranger enters the room, an alarm will be caused immediately quietly. You chose who will be informed per SMS or call if there is a break-in. Now you can listen undetected in the room and make the necessary steps. Ranges of application: flat, house, holiday house/flat, boat, camper, office, repair shop, atelier, shop, restaurant, garage, petrol station, etc.

Right placement

The Mobi-Click has a monitoring radius of approx. 5 meters with a angle of approx. 80°. To ensure best coverage for monitoring, place the Mobi-Click Compact in a corner.

Do not face the Mobi-Click at a window as movement outside the window can cause a false alarm. Best placement in the corner of a room (away from window) facing to the door.

ATTENTION!

In order to ensure the most effective monitoring possible over the greatest area, position the Mobi Click Compact in a place that allows common access to all rooms. (e.g. Hallway, stairway etc.)

Activate the alarm system



Press the two buttons when switching on until you hear a signal tone!



Activate alarm standby (home)

Press green button for about 3 seconds. Countdown starts (peep... peep...). You have 15 seconds to leave the room. To turn off: press green button within 15 seconds.

Start

- ▶ Activate the alarm system as described above. Mobi-Click Compact is now ready. To activate the alarm function in home-mode press the green button. Now the countdown starts automatically (peep...peep...). Quickly hide Mobi-Click Compact in the room and leave. After 15 seconds Mobi-Click is ready.
- ▶ The alarm function can also be activated from another mobile phone: just send the following SMS-command to Mobi-Click Compact "**set home**".
- ▶ Switch off Mobi-Click Compact:
 - When you enter the room you can switch off your Mobi-Click Compact by pressing the green button. Remember: You only have 15 seconds time, before the alarm starts! (When the alarm is turned off, you hear a triple tone.)
 - Or:
send the following SMS-instruction from you mobile phone to Mobi-Click Compact: "**reset home**". The monitoring will be switched off.

Set Baby Mobi-Click in the child's room



Baby phone

Mobi-Click Compact reacts because of the integrated **acoustic-sensor/microphone** not only when your child is crying, but also when it climbs out of bed silently (**motion-sensor**). You can listen quietly in the child's room at every time just to make sure everything is alright.

Range of application: at home, with relatives and friends, especially on holidays in hotel rooms, camping, etc.


The best is you test the acoustic-sensor by starting the Mobi-Click in test mode (see page 11)

Right time / placement

Parents often leave the child's room while the child is still awake. For avoiding wrong alarms, switch on Mobi-Click Compact not until your child is silent or send the instruction "**set baby call**" from your mobile phone to Mobi-Click. Mobi-Click will be switched on and calls you back immediately for confirmation. With the instruction "**hear**" you can also listen to your child's room later (see on p. 32).

Put the Mobi-Click in the direction of the child's bed or the door of the room. If the child is climbing out of bed the alarm will be caused immediately.

Important: The acoustic-sensor/microphone is set as it reacts not until the child is really awake and makes sounds 3 times within 30 seconds. (e.g. coughing only one time does not cause an alarm). The best is you test it. ("Test baby"). To increase sensitivity generally: "**set baby high**".

Activate the alarm system	Activate alarm standby (baby)
 BLUE + ON/OFF	 BLUE
Press the two buttons when switching on until you hear a signal tone!	Press blue button for about 3 seconds. Countdown starts (peep... peep...). You have 15 seconds to leave the room. To turn off: press blue button within 15 seconds.

Start

- ▶ Activate the alarm system as described above. Mobi-Click Compact is now ready. To activate the alarm function as babyphone press the blue button. Now the countdown starts automatically (peep... peep...). Quickly hide Mobi-Click Compact in the child's room and leave. After 15 seconds Mobi-Click is ready. (The baby should be sleeping this time!)
- ▶ The Mobi-Click baby sensor is set to MID as default. This can be adjusted by setting the sensitivity to LOW, MID or HIGH when you send the Set Baby command.
- ▶ The baby phone alarm function can also be activated from another mobile phone: just send the following SMS-command to Mobi-Click Compact "**set baby**".
- ▶ Switch off Mobi-Click Compact:
 - When you enter your child's room you can switch off your Mobi-Click Compact by pressing the blue button. Remember: You only have 15 seconds time, before the alarm starts! (When the alarm is turned off, you hear a triple tone.)
 - Or:
send the following SMS-instruction from your mobile phone to Mobi-Click Compact: "**reset baby**". The monitoring will be switched off.

Set ...

How do I choose the right alarm instruction?

Set Auto

Set Home

Set Baby

Set Vibra

Set Area

Set Move

Set Voice

Set All

Choose the right situation

Protect your vehicle (car, machine, motorbike etc.) reliably against thieves or burglars! **Vibration-sensor** and **locating** are activated.

Protect your home (flat, house, holiday house, bureau, etc.) reliably against burglary or unauthorized entering! **Motion-sensor** is activated.

The ideal Baby phone! Reacts not only when your child cries but also when it climbs out of bed! **Motion-sensor** and **acoustic-sensor** are activated.

Set sensors directly

Vibration-sensor: Reacts on smallest vibrations and is suitable for monitoring of vehicles of each kind.

Locating: For protecting individuals and localizing children and elder people but also for transporting values or demonstration-cars etc.

Motion-sensor (PIR): Registers every move within a distance of about 5 meters. Put your Mobi-Click with the sensor in direction of the corridor or the door but never in direction of the window.

Acoustic-sensor (microphone): The hyper-sensitive microphone reacts on voices or sounds in the monitored room.

All sensors are activated at the same time.

A combination of the sensors is also possible, e.g. "set vibra move".

Low/Mid/High

Can I change the sensitivity of the sensors?

Low

Mid

High

All integrated sensors of Mobi-Click are set in the factory optimal for the appropriate monitoring situation. The sensitivity can be adjusted with a simple instruction and so can be set to be more or less sensitive.

Choose a sensor and complete this sensor with a further instruction which influence the sensitivity:

In **set baby** you can adjust the sensitivity as required:

Set	baby	high
-----	------	------

e.g.:

Instruction	Sensor	Sensitivity	Action:
Set	Vibra	mid	vibration sensor: mid sensitivity
Set	Voice Move	high	acoustic and motion sensor: high sensitivity
Set	All	low	all sensors: low sensitivity

Test

Whether everything is set correctly? Test!

Test SMS

List of saved
SMS and telephone
numbers.

31.03.2004 10:11
COMPACT 42

Tel1 = SMS
+41791234567

Tel2 = call
0041791112233

Tel3 = off
+41527654321

Test Status

System and mobile
phone values.

31.03.2004 10:11
COMPACT 42

Battery : 5
Signal : 5

Zone : 2C57
PIN : 1234

AREA: : off
VIBRA : off mid

MOVE : on high
VOICE : on low

Test Alarm

Practice alarm.
Mobi-Click informs
all saved numbers
per SMS or call.

31.03.2004 10:11
HOLIDAY.HOUSE

Message: An alarm
was released!

AREA : off
VIBRA : off mid

MOVE : ALARM low
VOICE : ALARM high

Test Tel

Mobi-Click calls all
saved alarm
numbers with "Tel
1-3" in succession.
To save costs: do
not pick up the
phone.

SMS and telephone alarm numbers

31.03.2004 10:11
COMPACT 42

Tel1 = SMS
+41791234567

Tel2 = call
0041791112233

Tel3 = off
+41527654321

Date / time
Name and software version

Information per SMS
Telephone number 1

Information per call
Telephone number 2

Informed. Switched off
Telephone number 3

Confirmation of the instruction:

31.03.2004 10:11
HOLIDAY.HOUSE

Command:
SET NAME
HOLIDAY.HOUSE

Message:
Command OK

> End of Report

Date / time
changed name

"Echo" of the sent instruction
(control for the sender)

Message: instruction received
& operated correctly
End of the report

Status message

31.03.2004 10:11
COMPACT 42

Battery : 5
Signal : 5

Zone : 2C57
PIN : 1234

AREA: : off
VIBRA : off mid

MOVE : on high
VOICE : on low

Date / time
Name and software version

Battery strength (0...5)
Signal strength (0...5)

Actual location (GSM zone)
4-digit PIN-Code (or "off")

Sensors

Alarm status (on /off)
sensitivity (low/mid/high)

Problem message:

31.03.2004 10:11
HOLYDAY.HOUSE

Message:
BATTERY LOW

Area : off
VIBRA : off mid

MOVE : ALARM low
VOICE : ALARM low

Date / time
changed name

Message:
Battery/Accumulator low

Control for the receiver if all
sensors are still working
regularly and have the right
status despite low battery
voltage

Hear

Eavesdrop in? Yes, but pay attention...!



Protection of the private sphere is in the constitution of many countries. It should not and is not allowed to abuse Mobi-Click for unauthorized monitoring purposes!

The instruction "**Hear**" causes a soundless call from Mobi-Click to you after you have received your SMS. Now you can listen in the room or place without being detected. This is useful if you, for example, use Mobi-Click as a baby phone and you want to control if everything is OK.

e.g.

Instruction	Add-on	Action
Hear		Mobi-Click calls your mobile phone back

Hear	Tel2	Mobi-Click calls back the pre-programmed telephone alarm number 2
Hear	Tel3	Mobi-Click calls back the pre-programmed telephone alarm number 3

The instruction "**Hear Tel2**" or "**Hear Tel3**" is useful if, for example, your fix net telephone does not have the possibility of writing a SMS but you want to be called back on the fix net nevertheless.

Set Code / PIN

PIN-Code – How to protect against outside access?

With this function Mobi-Click can be protected against outside access. The PIN-code consists of the word "**PIN**" and a code. The code is always 4-digit and cannot contain any signs, but just digits (e.g. "1234").

IMPORTANT:

If you have saved your own Mobi-Click text responses, then all instructions which you transmit to Mobi-Click must have the same text and PIN-code at the end, e.g. "**set auto pin 1234**". Without the code the instruction will not be fulfilled. If you forgot to attach the PIN-code or attached a false PIN, you get a message with "Access denied!". (To save costs, Mobi-Click sends you this message only once).

Action	Instruction	Designation	Description
Set	code	1234	write and save PIN-code
Reset	code	pin 1234	switch off PIN-code temporarily

ATTENTION!

Lost PIN-Code? What to do?

It is possible to do a general reset to factory default settings when you start the Mobi-Click Compact in alarm mode (see page 11). This will also reset the PIN-Code.

After switching to alarm mode, you will hear 5 beeps, after which you must press and hold the blue button until you hear a triple tone. Afterwards all settings, including the PIN-Code will be reset to factory default settings.

Set Name / Text

Can I write personal alarm messages?

Individual alarm messages:

Personal texts are used to describe an alarm which had happen more exactly, especially if the alarm message goes to a third person or if there are several Mobi-Click devices in order.

Change name of Mobi-Click:

Set	name	Maserati	Write / save new name (max. 10 signs)
Reset	name		Name will be deleted (Mobi-Click is called "Mobi-Click")

Change name of system alarm:

Set	alarm	text	Babyphone Nathalie (example, max. 21 signs)
Reset	alarm	text	Text returns to factory default

e.g.:

Set name Maserati

Mobi-Click is now called "Maserati"

Reset name

Mobi-Click is called "Mobi-Click" again.

Set alarm text Baby phone Nathalie

System alarm is called "Baby phone Nathalie" now.

Reset alarm

Alarm message is called "system alarm" again.

Individual alarm texts:

For every sensor can be assigned a personal text which is allowed to consist of 21 signs.
See the following samples:

Set	voice	text	Baby is crying!
Set	move	text	Burglar in the house!
Set	vibra	text	Alfa Romeo stolen!
Set	area	text	Left way to school!

Reset **e.g. vibra** **text** (example for reset text)

Reset **all** **text** (example for reset all text)

Set voice text Baby is crying!


When acoustic sensor / microphone is activated there will be the alarm message: "Baby is crying!"

Set area text left way to school!

When e.g. your child leaves the way to school you get a message "left way to school!"

Reset all text

No individual messages.



Reset System:

Keep the two buttons pressed, than you hear 5 times a beep. Stop pressing the ON/OFF-button, you can hear a triple tone. Keep pressing the blue button, till the yellow LED lights.

Test Text

How can I test if the text is correct?

As per page 35 different SMS text can be assigned to different sensors. In order to test please follow the instructions below:

Send one of the following SMS to Mobi-Click to test the associated sensor:

Instruction	Text	Action
Test	Text	The alarm SMS text reply and the e-mail address will be sent.
Test	Text1	The alarm SMS text reply will be sent.
Test	Text2	The area and the vibra SMS text reply will be sent.
Test	Text3	The move and the voice SMS text reply will be sent.

Set E-mail

Individual SMS-instructions

How can I use the notification by e-mail?

Action	Instruction	Description
Set	Email aaa	Save e-mail address (aaa = address, till 23 signs)
Reset	Email	Notification by e-mail deactivated
Set	SMS *bbb	Notification by e-mail activated (*bbb = SC-number, till 8 signs)
Test	Text	Acknowledgement to the indicated e-mail address

You can also receive notification by e-mail. In addition you need an e-mail receiver to be informed in the case of emergency. This is useful if, for example, your daughter is to be informed, however she is in the office all day so a message is more suitable by e-mail, since she may not use her mobile phone during the day, or does not have her own one.

This instruction can be deactivated simply with the instruction "Reset Email". In order to determine whether the e-mail address of the receiver was stored correctly, you send the instruction "Test Text" to Mobi-Click, and you receive a reply, in which the stored e-mail address is indicated.

You can change this e-mail address also at any time, by again sending a SMS with the instruction "Set Email aaa" and "Set SMS *bbb" to Mobi-Click Compact. The old stored e-mail address is automatically overwritten.

Attention: The asterisk before the service centre number (SC number) must be always set!
You can get the service centre number from your provider.

Set Zone / Area

Security zone and localization of persons or objects

With Mobi-Click you can define protection zones, e.g. your child's way to school. If the child leaves this area (e.g. because it enters a stranger's car) you will be warned immediately per SMS and you can monitor the situation if necessary.

Set	Zone	Define security zone
-----	------	----------------------

Learning mode is activated. Mobi-Click gives a short peep every 20 seconds. When finding a new unknown GSM zone the dual tone signal is heard. Interrupt learning mode: when Mobi-Click is switched off previously learnt zones remain saved. Reactivate learning mode: "set zone". Mobi-Click can store a maximum of 48 zones. When this number is exceeded there will be an error tone (peep) and the LED lights continuously. Zones will remain saved. Stop learning mode: Switch off Mobi-Click. **"Reset zone"**: Security zones will be deleted.

On the way with the car:

It is possible that not all GSM cells can be detected immediately during the security zones learning process (especially when driving the children's path to school). Some cells may be working to capacity and therefore they can not be registered by Mobi-Click. That is why it is advisable for urban areas to cross a security zone slowly or more than once if possible, this allows for every possible GSM cell to be registered by Mobi-Click. (Security zones can be tested with "**Test Area**".)

Activate locating	
Set	Area
Set	Auto

Set Alarm

How can I connect extern devices?

Mobi-Click can be connected to an external contact. This contact generates an alarm report to the programmed target call number in the programmed communication forms (SMS, call, e-mail).

Function/Software

The interface of Compact is normally served for the data-communication to and from external system-components. The logical standby level is in this case LOW. If there is a connection, then this stand-by level will logically be pulled up to HIGH. Therewith Mobi-Click Compact recognises with the next set function (SET XXX) or with the next mode shift (SET ALARM) a standby power connection and it will begin to monitoring this additional sensor automatically. It is also important to make the connection before activating the Mobi-Click device via SMS or buttons.

Monitoring together with other sensors

When one of the sensors is switched on, then this contact will be monitored automatically as well (e.g. SET HOME, SET VIBRA etc.).

Sole Monitoring

With the command SET ALARM Mobi-Click will not only put into the "security-mode". When a contact is connected it will be focused automatically. Because all the other sensors will not be activated with this command, solely this contact will be monitored.

Alarm display

Because the contact itself does not own a sole-alarm-display, an identification is given as follows: if the alarm report is given by SMS or e-mail, then a release of the contact can be determined because even though there was an alarm reported, the sensors had no sole release.

Important: Switch your Mobi-Click Compact only on/off when the contact is not connected yet. Else, it can be possible that the connected hardware will not be interpreted rightly and/or the switching on/off function will not function in proper form.

Declaration of Conformity

Technical data

We, MOBI_CLICK AG; Alte Steinhauserstrasse 19; CH-6330 Cham/ZG

declare under sole responsibility that the product:

Mobile Phone and Security System Mobi-Click Compact (suitable for GSM/E-GSM 900 MHz and PCN 1800 MHz)

To which this declaration relates, is in conformity with the following essential requirements of the Directive 1999/5/EC: Article 3.1 a), 3.1 b) and 3.2

The product has been tested against the following standards:

EN 301 511	Harmonised Standard for Mobile Stations in the GSM900/1800 Bands
EN 301 489-01	Electro Magnetic Compatibility Standard for Radio Equipment and Services
EN 301 489-07	Specific (EMC) Conditions for Mobile Radio Equipment, GSM 900/1800
EN 60950/IEC 950	Safety of Information Technology Equipment
EN 50360	Product Standard to demonstrate the Compliance of Mobile Phones with the Basic Restrictions related to Human Exposure to Electromagnetic Fields
EN 50361	Basic Standard for the measurement of Specific Absorption Rate related to Human Exposure to Electromagnetic Fields from Mobile Phones
1999/519/EC	Council Recommendation on the Limitation of Exposure of the General Public to Electromagnetic Fields

The product is marked with the CE marking and Notified Body number according to the Directive 1999/5/EC: Identification mark: 168

Place of Issue: Cham/ZG

Date of Issue: 17. 12. 2003

Temperature range:	working range -10°C to +55°C storage range -25°C to +80°C
Weight:	78g (including battery)
Dimensions:	106 mm x 38 mm x 19 mm (LxWxH)
Operating Voltage:	3,45 Volt to 4,2 Volt (nominal 3,6 Volt)
Recharge time:	approx. 40 Min. (for a fully discharged battery)
Standby-Time:	up to 290 hrs. (telephone mode) up to 200 hrs. (monitoring mode)
Module:	Sagem M0110d
Battery:	BAK 063448S2 Lithium Ion
Talk time:	up to 120 min.
SIM-Card:	3 Volt
Frequency band:	EGSM900 (880 to 960 MHz) DCS1800 (1.710 to 1.880 MHz)
GSM-Class:	Class 4 (2 Watt) as per EGSM900 Class 1 (1 Watt) as per DCS1800
Data Service:	SMS
Mobi-Click is designed to the following standards:	
GSM 03.03: "Digital cellular telecommunications system (Phase 2+); numbering, addressing and identification". Version 6.6.0.	
GSM 03.13: "Digital cellular telecommunications system (Phase 2+); Discontinuous Reception (DRX) in the GSM system". Version 6.0.0.	
GSM 04.02: "Digital cellular telecommunications system (Phase 2+); GSM Public Land Mobile network (PLMN) access reference configuration". Version 6.0.0.	
GSM 04.03: "Digital cellular telecommunications system (Phase 2+); Mobile Station- Base Station System (MS-BSS) Interface Channel structures and access capabilities". Version 6.0.0.	
GSM 04.04: "Digital cellular telecommunications system (Phase 2+); Layer 1 General requirements". Version 6.0.0.	
GSM 04.05: "Digital cellular telecommunications system (Phase 2+); Data Link (DL) layer General aspects". Version 6.0.1.	
GSM 04.07: "Digital cellular telecommunications system (Phase 2+); Mobile radio interface signalling layer 3 General aspects". Version 6.5.1.	
GSM 04.08: "Digital cellular telecommunications system (Phase 2+); Mobile radio interface layer 3 specification". Version 6.11.0.	